


NOTE:

- SIDEWALL SPR. DEFLECTOR TO BE INSTALLED WITH THE DEFLECTOR PARALLEL WITH THE CEILING. IF THE CEILING IS SLOPING SPRINKLER DEFLECTOR SHOULD FOLLOW THE CEILING SLOPE (3RD FLOOR ONLY WHERE APPLICABLE).



RISER SCHEMATIC N.T.S.

